

Get Connected - DStv



No satellite dish? No problem! You can now access DStv using our fibre system – just follow the simple steps below.

Step 1

Do you already have the Global fibre to copper device installed in your home? If you don't have one of these fibre converters, please contact us to order your device on

011 100 0210 or email sales@clearaccess.co.za

Fibre to copper device



F-Type Connector

Step 2

Connect your decoder with a high quality F-type to F-type coaxial flylead.

Step 3

After you've connected your decoder as per the guide below, reset it to factory defaults, let it scan, sit back and enjoy your viewing experience.

Decoder Type	Cables needed	DStv Switch	Connection Guide
Single View Decoder SD/HD	One	No	Connect one high quality F-type to F-Type Coaxial Flylead from your Fibre converter to your 'LNB input' on your decoder
2 Tuner PVR decoder	Two	No	Connect two high quality F-type to F-Type Coaxial Flyleads from your Fibre converter to your 'LNB inputs' on your decoder
4 Tuner PVR decoder	Four	No	Connect four high quality F-type to F-Type Coaxial Flyleads from your Fibre converter to your 'LNB inputs' on your decoder
Explora & Explora 2	Five	Yes	Connect four high quality F-type to F-Type Coaxial Flyleads from your Fibre converter to your DStv Switch; then connect one cable from the A or B port to the Unicable input on your decoder



Call DStv on 011 289 2222 for support regarding your decoder.

